



**Operating Instructions**  
**(SKU#01227099 YJ WITCH OF STOLEN SOULS)**

1. Carefully remove all the parts from the package including: 1 metal stand, 2 metal poles, 1 witch head with hat, 1 witch body with costume, 1 lantern in brown box, 1 AC/DC adapter with 1 screw and 1 screw nut in small box.




2. Connect the metal poles to the metal stand. Be sure to connect I to I first, then connect to the stand. Connect them properly, rotating them until a “click” sound is heard. See diagram A.



3. Connect the body to the metal stand, be sure to align the hole on metal pole to the hole on plastic, and then secure the body with the screw and screw nut provided. Be sure to connect them properly. See diagram B.

4. Carefully place the head onto the body. Gently connect until it is tight and secure. Adjust the clothes of the witch until desired look is achieved. Small vecro has been sewn on the front of the inside of the costume to make easier to shape. See diagram C.




5. Hang the lantern from the metal hook which is located in the palm of hand. See diagram D.

6. Connect the AC/DC adapter to the jack which is located at the front chest of the body. Once connected, insert the AC/DC adapter to the appropriate input.

7. This product comes with a built in motion sensor. Connect the wire pin (which comes from the hand sleeve) to the pin box (which is located at the bottom of the lantern). Turn the switch of the lantern to “II” position (which is located at the bottom of the lantern, and 3 AA batteries included for demo purposes only), the lantern will light up always. The witch will be activated by motion, and the lantern will have motion and sound at the end of each phrase the witch speaks. See diagram D1.


8. The item is equipped with TRY ME and STEP PAD features. Try Me button and Step Pad not included, but are sold separately.

9. To adjust the volume of product, turn dial as shown in diagram E.



10. When storing this product, carefully remove the product from where it has been placed to avoid any undue strain or stress on the product.

11. When not in use, turn the switch of the lantern to “OFF” position. Store the product neatly in a dry, cool location protected from sunlight.



**Made In China**