



Swinging Elf

Assembly & Operating Instructions

PLEASE KEEP A COPY OF YOUR RECEIPT WITH THESE INSTRUCTIONS.

WARNING: Do not turn prop on until fully assembled.
Stay clear of the prop while operating. Keep all plastic & wire parts away from children.

Prop is intended for use with included components.
For optimum performance, do not add additional weight onto prop.

Estimated Build Time: 10 minutes


PARTS:



- | | | |
|-----------------------------------|------------------------|------------------------------|
| A. Swing Base | E. Metal Swing Bar | I. Cotter Pins (x2 +1 extra) |
| B. Lower Support Pole | F. IR Sensor | J. Zip Tie (x2 +1 extra) |
| C. Upper Support Pole | G. 6V 2A Power Adapter | K. LED Lights |
| D. Swinging Mechanism/Control Box | H. Body | |


ASSEMBLY

1



Place the Swing Base (Part A) on a flat suitable surface.

2



Attach the Lower Support Pole (Part B) to the Swing Base (Part A), Ensuring the spring pin snaps & locks into place.

3



Attach the Upper Support Pole (Part C) to the Lower Support Pole (Part B), Ensuring the spring pin snaps & locks into place.

4



Place the Body (Part H) onto the assembled frame by threading it from the bottom.

5



Attach the arms from the Body (Part H) to the Lower Support Pole (Part B) by sliding the prongs into the corresponding bracket, securing them in place with the Cotter Pins (Part I). Secure the zipper on the back of the Body (Part H).

6



Secure the ropes on the Swing Base (Part A) through the hands on the Body (Part H), securing the hands hook & loop strips.

7




Hang the Swinging Mechanism/Control Box (Part D) on a strong, sturdy pole using the hook & loop strap on the mechanism. Tightly secure the hook & loop strap around pole then secure it in place by tightly wrapping a Zip Tie (Part J) around the strap to prevent excess movement of the mechanism.

8



Lay the Metal Swing Bar (Part E) into the hooks on the Swinging Mechanism/Control Box (Part D) ensuring the holes on the bar to their corresponding plastic pegs on the plastic hooks, holding the bar in place.

9



Hang the assembled Swinging Elf from the Metal Swing Bar (Part E) by inserting the metal hooks coming from the Swing Base (Part A) into the holes on the Metal Swing Bar (Part E).

10




Connect the LED Lights (Part K) to the corresponding wire coming from the Swinging Mechanism/Control Box (Part D) & run them down & around one rope & up the other.

11



Insert the wire from the IR Sensor (Part F) to the jack on the Swinging Mechanism/Control Box (Part D) Labeled "IR Sensor (Part F)," then adhere the IR Sensor (Part F) as desired.

12



Plug one end of the 6V 2A Power Adapter (Part G) into the "Power Adapter" jack on the Swinging Mechanism/Control Box (Part D) & plug the other end into a suitable outlet.

ASSEMBLY

13



MODE SWITCH

Turn the switch to the ON Position to activate the prop via IR Sensor (Part F).

14



VOLUME CONTROL

The volume can be adjusted on the Swinging Mechanism/Control Box (Part D) by turning the volume control knob.


IMPORTANT:

1. The infrared sensor distance & ambient temperature are directly related. When the body temperature (98.6° F) is different to the ambient air temperature, the infrared sensor distance will be farther. When the body temperature (98.6° F) is close to the ambient air temperature, the infrared sensor distance will be shorter.
2. Do not use this item in an environment where air currents are caused by a window, air conditioning, or air outlet.
3. Do not have the infrared sensor face a direct source of heat such as a heater.

WARNINGS

- Keep away from open flame and direct heat sources.
- This product is designed for indoor or covered porch use only, & should not be placed outdoors subject to the weather.
- This item is not a toy. For decoration only.
- Choking hazard due to small parts.
- Keep all plastic & wire parts away from children.
- This product is intended for use by persons 15 years of age & older. Not intended for use by children ages 14 & under.
- PLEASE KEEP A COPY OF YOUR RECEIPT WITH THESE INSTRUCTIONS.

Questions about setup?
There's no need to go back to the store.
Ask the Holiday Tech Squad!



HTechSquad@SpiritChristmas.com
1-888-526-2169

